



DreamKuts – IMPORTANT NOTICE!



February 2007 – Important Notice about DreamKuts!

1. DreamKuts will **NOT** cut chipboard – in either cutting slot!
In fact, attempting to cut chipboard will cause severe damage to your unit by separating the cutting blades from their proper positions. This will force the blades to “score” rather than cut.
2. The two paper guides on the front cutting slot are anchored permanently and are not meant to move. These guides ensure three even strips cut at 4” wide. This front slot is for 12” wide paper only.
3. On the back slot, the paper guide adjustments on both sides are self-centering and are to be adjusted by using both hands at once, one on each side to properly engage the self-centering gears.
4. The decorations that appear to be turning wheels on both sides at the back of the machine are not intended to move

If you have any additional questions about any products from Zutter Innovative Products, do not hesitate to email the Zutter Zisters at customerservice@zutterzisters.com

Duplication of this information is permitted only for the educational purposes of scrapbook and craft retailers and scrapbook instructors and is provided as a service by Zutter Innovative Products.

©2007 Copyright Zutter Innovative Products and www.ZutterZisters.com. All Rights Reserved.